

How to Add the Power Electronics Add-On to the System Definition

Procedure

The OPAL-RT Power Electronics Add-On for NI VeriStand is designed to plug-in to NI VeriStand via a *Custom Device*. Follow the steps below to add the custom device to the VeriStand System Definition.

1. Create a VeriStand Project by clicking **Default Project** and provide it with a representative name
2. In the VeriStand Editor, click **Configure...** to launch the System Explorer.
3. Expand the System Definition tree until the **Custom Devices** section is reached
4. Right-click the **Custom Devices** section and navigate to **OPAL-RT>>Power Electronics Add-On**. Wait for the Power Electronics Add-On Main Page to load.
5. **Save** the System Definition.

