

1.0 Opening the Example

Example Path: <Public Documents>\National Instruments\<NI VeriStand 20xx>\Examples\OPAL-RT\Power Electronics Add-On\Three Phase Rectifier\Project\Three Phase Rectifier.nivsprj

- Before making changes to the original example, consider creating a backup copy of the project by copying and pasting the example folder to another directory (such as the Desktop).
- Open VeriStand and select **Browse** on the Main screen.
- Browse to the copied example folder and select the **VeriStand Project (.nivsprj)** file from the **Project** folder.

 If using Veristand 2018, select the Project file with the extension **.nivsprj**.

