

# ePHASORSIM User Documentation

- Requirements
- Introduction
  - Solver Block
  - Mask
    - Network data
    - Library
    - Simulation settings
    - Scripting
- Quick Start
  - Excel Input File
  - PSSe Input Files
  - CYME Input File
  - PowerFactory Input File
- Native Library
  - Introduction to Excel Template
  - Bus
  - Current Injector
  - Voltage Source
    - Positive Sequence Voltage Source
    - Multiphase Voltage Source
  - Machine
    - Synchronous Machine
    - Induction Machine
  - Exciter
  - Power System Stabilizer (PSS)
  - Turbine and Governor
  - Load
    - Positive Sequence Load
    - Multiphase Load
  - Shunt
    - Positive Sequence Shunt
    - Multiphase Shunt
  - Line
    - Positive Sequence Line
    - Multiphase Line
      - Calculation of Power Transfer
  - Transformer
    - Positive Sequence Transformer
    - Multiphase Transformer
  - Switch
  - Fault
    - Positive Sequence Fault
    - Multiphase Fault
  - Probe
    - Multiport Thevenin Impedance Equivalent
- User Defined Libraries
  - Modelica Based Library
    - Terminologies
    - GenUnit FMU
      - Create a New Component
      - Register Component in FMUGlossary
      - Create a GenUnit
      - FMUCreator
      - Import from Excel Input File
      - Importing from PSS/e, CYME and PowerFactory
      - I/O Pins for GenUnit
    - Single Component FMU
      - Create Single Component FMU
      - Import Using Excel Template v2.0
      - I/O Pins for Single Component FMU
    - Existing Models
  - Simulink Based Library
    - Protection Relay Models
      - Inverse Time Overcurrent Relay
      - Double Blinder Out-of-Step Relay
    - Controller Models
- Third Party Data Formats
  - PSS/e
    - PSS/e RAW file
    - PSS/e DYS file
    - I/O Pins for PSS/e Data
  - CYME

## Search this Documentation

### Contact Us

If you have any questions, please refer to our online **Customer Support Knowledge Base**:

<http://www.opal-rt.com/support-knowledge-base/>

...or contact the **Support team** using our web form:

<http://www.opal-rt.com/contact-technical-support/>

If you don't find answers for the issues you are having, do not hesitate to contact us.

### Disclaimer

© OPAL-RT 2020

Information in this website is subject to change without notice.

No part of this documentation may be copied or reproduced in any form or by any means without written permission from OPAL-RT TECHNOLOGIES Inc.

OPAL-RT TECHNOLOGIES makes no representation or warranty with respect to the adequacy or accuracy of this documentation or the software which it describes. In no event will OPAL-RT TECHNOLOGIES or its direct or indirect suppliers be liable for any damages whatsoever including, but not limited to, direct, indirect, incidental, or consequential damages of any character including, without limitation, loss of business profits, data, business information, or any and all other commercial damages or losses, or for any damages in excess of the list price for the license to the software and documentation.

### Copyright

All product names, logos, and brands are property of their respective owners. All company, product and service names used in this website are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.

- Unbalanced System
  - Supported Components
    - Bus Data
    - Busway Data
    - Cable and Overhead Line Data
    - Fuse Data
    - Spot Load and Distributed Load Data
    - Shunt Capacitor Data
    - Shunt Reactor Data
    - Switch, Breaker and Recloser Data
    - Transformer Data
    - Regulator Data
    - Voltage Source Data
    - Electronically Coupled Generator ECG
    - Synchronous Generator
  - Excel File Load Flow Analysis
  - Generate Power-Flow Results from CYME ver. 7.2
- Balanced System
- I/O Pins for CYME Data
- PowerFactory
  - Prepare a Compatible DGS File
  - Specs for DGS File Format
  - I/O Pins for PowerFactory Data
- Power-Flow
- Python API
- Parallel Simulation
- Error Codes
  - No License
  - Incorrect MATLAB Directory
  - The Input Files Do Not Exist
  - InitError
  - DataError
  - NaN Not a Number Cell Evaluated in Excel Input Sheet
  - Power-Flow Errors
  - To Get More Logs and Verbose Output
  - If Everything Is OK
  - Troubleshooting with IRTS.log
- Migration Notes
- ePHASORSIM Release Notes