

Scripting

Use post-init script: If checked, ePHASORSIM runs the python script defined in **Post-init script (*.py)** at the beginning of the simulation.

If this feature is unchecked, the user can apply ePHASORSIM API routines later on in an interactive mode through the RT-LAB Python API console.

For more information about this feature, refer to the [Python API](#) section.

