

# OP8666 Receiving and Verification

After opening the package, remove the equipment and components.  
Locate all the items described in Standard Hardware section below.  
Make sure that they are undamaged.

If there are missing or damaged items, please contact your **local representative** or [OPAL-RT Technical Support team](#).

## Standard Hardware

The OP8666 package includes the following items:

Item	QTY	Description	Part Number
OP8666	1	OP8666 DSP Controller Board	T00-8208
Power Supply	1	Input: 100-240 V~ 0.8A 50/60 Hz Output: 15 VDC, 2 A	-
19" Rack mounting kit	1	2 extension plates and mounting hardware	-



OPAL-RT strongly recommends the use of **anti-static wrist straps** whenever handling any electronic device provided by OPAL-RT. Damage resulting from electrostatic charges is not covered by the manufacturer's warranty.