

OP5357-OP5358 DB37F Pin Assignment

P1 Connector				P2 Connector			
DB37	Channel	DB37	Channel	DB37	Channel	DB37	Channel
1	+IN00	20	-IN00	1	+IN16	20	-IN16
2	+IN01	21	-IN01	2	+IN17	21	-IN17
3	+IN02	22	-IN02	3	+IN18	22	-IN18
4	+IN03	23	-IN03	4	+IN19	23	-IN19
5	+IN04	24	-IN04	5	+IN20	24	-IN20
6	+IN05	25	-IN05	6	+IN21	25	-IN21
7	+IN06	26	-IN06	7	+IN22	26	-IN22
8	+IN07	27	-IN07	8	+IN23	27	-IN23
9	+IN08	28	-IN08	9	+IN24	28	-IN24
10	+IN09	29	-IN09	10	+IN25	29	-IN25
11	+IN10	30	-IN10	11	+IN26	30	-IN26
12	+IN11	31	-IN11	12	+IN27	31	-IN27
13	+IN12	32	-IN12	13	+IN28	32	-IN28
14	+IN13	33	-IN13	14	+IN29	33	-IN29
15	+IN14	34	-IN14	15	+IN30	34	-IN30
16	+IN15	35	-IN15	16	+IN31	35	-IN31
17		36		17		36	
18	Reserved	37	Reserved	18	Reserved	37	Reserved
19				19			

