


# Hardware installation

## I/O cards installation

Base + autres

## Connections

All connectors are located in the back of the chassis.



power, reseau

Power backplane Batt, ECU, GND

USB adapter