

OP5650

LEGACY PRODUCT

Please note that the OP5650 has been replaced in the OPAL-RT simulator platform offering by the [OP5705XG Versatile Real-Time Digital Simulator](#) (User Manual).

- [OP5650: Safety Warnings, Maintenance & Repair | Avertissements de sécurité, maintenance & réparation](#)
- [OP5650 System Description](#)
- [OP5650 Receiving and Verification](#)
- [OP5650 Hardware Interface](#)
 - [OP5650 Front Connectors](#)
 - [OP5650 Rear Connectors](#)
- [OP5650 Installation and Configuration](#)
- [OP5650 IO Connectors](#)
- [OP5650 Connecting Monitoring Devices](#)
- [OP5650 Pin Assignments](#)
- [OP5650 Specifications](#)



Please note that all **Safety Warnings**, as well as all **User Installation, Handling & Warning Icons**, can be [found here](#) in both English and French.

Veillez noter que tous les **avertissements de sécurité**, ainsi que toutes les **icônes d'avertissement d'installation, de manipulation et d'utilisateur**, peuvent être [trouvés ici](#) et sont disponibles en anglais et en français.

For the **OP5###'s Maintenance & Repair** section, [see here](#).

Pour la section **Maintenance et réparation de l'OP5###**, [voir ici](#).